




User's manual of 410 cash drawer



A. How to use:

a. Take out cash drawer from carton, then get the key and RJ11 cable from plastic bag, open the drawer by inserting key and 90 clockwise, check its flexibility, move to next operation.

b. Adjust desk to horizontal and put cash drawer on it



c. Connect cash drawer with PC or printer by RJ11 cable

B. The operation of lock and its function

Cash drawers of 335 series have 3 position lock as below:

a. Controlled mode: the left picture is controlled mode, cash drawer can be opened by PC or printer.

b. Locked mode: Insert key and 90 clock wise, it comes to locked mode


c. Manual mode: Insert key and 90 anticlockwise, cash drawer is opened

C. Packing list: 1. Cash drawer 1 PC 2.Key 2PCS 3. RJ11 cable 1 PC 4. User's manual 1 PC.

A. How to use:

a. Take out cash drawer from carton, then get the key and RJ11 cable from plastic bag, open the drawer by inserting key and 90 clockwise, check its flexibility, move to next operation.

b. Adjust desk to horizontal and put cash drawer on it



c. Connect cash drawer with PC or printer by RJ11 cable

B. The operation of lock and its function

Cash drawers of 335 series have 3 position lock as below:

a. Controlled mode: the left picture is controlled mode, cash drawer can be opened by PC or printer.

b. Locked mode: Insert key and 90 clockwise, it comes to locked mode

c. Manual mode: Insert key and 90 anticlockwise, cash drawer is opened

C. Packing list: 1. Cash drawer 1 PC 2.Key 2PCS 3. RJ11 cable 1 PC 4. User's manual 1 PC.