



Barcode Scanner

Manual Guide

DC7142

General Settings



Factory Default



Display version information



Add CR suffix



Clear CR suffix



Add CR suffix and LF suffix



Clear CR suffix and LF suffix

Buzzer Setup



High volume -Default



Medium volume



Low volume



Volume Off

Lan gu ag e



American Keyboard



Germany



France



Sweden



CZECH



Finland



Russia



SW ITZERLAND_FRENCH



ARAB



Norway



HUNGARY




Denmark



Spain



Italy

 ICELAND	 SLOVENIA
 CROATIA	 ALBANIA
 SERBIA_LATIN	 SERBIA_CYRILLIC
 CZECH_QWERTZ	 ESTONIA
 LITHUANIA	 IRISH
 FAEROESE	 TURKEY_F
 TURKEY_Q SLOVAKIA	
JAPAN: Transmit Japanese in word, scan the following barcode configuration:	



(82100128.)



(8210130.)



(8210083.)

JAPAN: Transmit Japanese in Notepad, scan the following barcode configuration:























(82100128.)



(8210130.)

Barcode Type ON/OFF

 All BARCODE TYPES(ON)*	 All BARCODE TYPES(OFF)
 1D CODE(ON)*	 1D CODE(OFF)
 2D CODE(ON)*	 2D CODE(OFF)
 Default all UPC-A settings	
 UPC-A(ON)*	 UPC-A(OFF)

 <p>UPC-A Check Bit (ON)*</p>	 <p>UPC-A Check Bit(OFF)</p>
 <p>Default all UPC-A settings</p>	
 <p>UPC-E0(ON)*</p>	 <p>UPC-E0(OFF)</p>
 <p>UPC-E Check Bit(ON)*</p>	 <p>UPC-E Check Bit(OFF)</p>
 <p>UPC-E1(ON)*</p>	 <p>UPC-E1(OFF)</p>
 <p>UPC-E to UPC-A(ON)</p>	 <p>UPC-E to UPC-A(OFF)*</p>



UPC-A to EAN-13(ON)



UPC-A to EAN-13(OFF)*



Default all EAN/JAN-8 settings



EAN/JAN-8(ON)*



EAN/JAN-8(OFF)



Default all EAN13/JAN-13 settings



EAN-13/JAN-13(ON)*



EAN-13/JAN-13(OFF)



ISBN(ON)



ISBN(OFF)*



Default all CODE 128 settings



CODE 128(ON)*



CODE 128(OFF)



Default all GS1-128 settings



GS1-128(ON)*



GS1-128(OFF)



ISBT-128(ON)



ISBT-128(OFF)*



Default all GS1 DataBar Omnidirectional settings



GS1 DataBar Omnidirectional(ON)*



GS1DataBar Omnidirectional(OFF)



Default all Interleaved 2 of 5 settings



Interleaved 2 of 5(ON)*



Interleaved 2 of 5(OFF)



Default all Matrix 2 of 5 settings



Matrix 2 of 5(ON)



Matrix 2 of 5(OFF)*



Default all CODE 39 settings



CODE 39(ON)*



CODE 39(OFF)



Code39 Check Bit(ON)*



Code39 Check Bit(OFF)



Code 39Full ASCII(ON)



Code39Full ASCII(OFF)*



CODE 32 PAPA F (ON)



CODE 32 PAPA F(OFF)*



Default all CODE 93 settings



CODE 93(ON)*



CODE 93(OFF)



Default all CODE 11 settings



CODE 11(ON)



CODE 11(OFF)*



Default all CADABAR settings



CODABAR(ON)*



CODABAR(OFF)



Default all NEC 2 of 5 settings



NEC 2 of 5(ON)*



NEC 2 of 5(OFF)



Default all Straight 2 of 5 Industrial settings



Straight 2 of 5 Industrial(ON)



Straight 2 of 5 Industrial(OFF)*



Default all Straight 2 of 5 IATA settings



Straight 2 of 5 IATA(ON)



Straight 2 of 5 IATA(OFF)*



Default all MSI settings



MSI(ON)



MSI(OFF)*



Default all QR CODE settings



QR CODE(ON)*



QR CODE(OFF)



Default all Matrix settings



Data Matrix(ON)*



Data Matrix(OFF)



Default all PDF417 settings



PDF417(ON)*



PDF417(OFF)



Default all Aztec code settings



Aztec code(ON)*



Aztec code(OFF)



Default all China Post (Hong Kong 2 of 5) settings



China Post (Hong Kong 2 of 5)(ON)



China Post(Hong Kong 2 of 5)(OFF)*



Default all Korea Post settings



Korea Post(ON)



Korea Post(OFF)*



Default all Han Xin code settings



Han Xin code(ON)



Han Xin code(OFF)*



Default all Maxi code settings



Maxi code(ON)



Maxi code(OFF)*



Default all Gs1 Composite Code settings



Gs1 Composite Code(ON)



Gs1 Composite Code(OFF)*



Default all Micro PDF settings



Micro PDF(ON)*



Micro PDF(OFF)



Default all Codablock A settings



Codablock A(ON)



Codablock A(OFF)*



Default all Codablock F settings



Codablock F(ON)



Codablock F(OFF)*