





Hi, this is receipt printer

# User's Manual



## Installation & Usage

- 1 Open the paper container**  
Please open the paper container with the uncovering handle.  

- 2 Put paper into the paper container**  
Feed the receipt paper correctly into the paper container in the direction as shown, and pull some paper outside the cutter.  

- 3 Power on printer**  
Close the cover of the paper container and press the power Button for one second to power on printer.  


**Note** Remove the insulating tape from the battery contacts prior to product use.

## APP Download


- a** Scan the QR code below to download 4BarCode APP



- b** More software instructions can be found in the 4BarCode APP

**Note** 1. Make sure Bluetooth is turned on  
2. Granted location permission

## Packing List



## Key Function Description

Power Key	Feed key	Function description
Press 1s and release	—	In power off mode to switch on the printer.
Press 1s and release	—	In power on mode to turn off the printer.
—	Press	Feed paper
When the printer is turned on, turn it off first, then press and hold the FEED key and press POWER key, wait 2-3 seconds, both key are released at the same time, the printer will print out the current status and printer settings.		Printer selftest page
When the printer is turned on, turn it off first, then press and hold the FEED key, and then press and hold POWER key, wait for 2 seconds, release the POWER key, wait for 20 seconds or so, after all the indicators of the printer go out, release the FEED key.		Initialization settings

## Indicator Light Prompt

Power Indicator	Status Indicator	Prompts of Indicator
Green light is normally on	—	No Bluetooth connection
Green light is normally on	Green light is normally on	Bluetooth is connected
Red light is normally on	—	Battery level low (<10%)
Green light is normally on	Red light is blinking at a frequency of 500ms	Paper end
Green light is normally on	Red light is blinking at a frequency of 500ms	Printer overtemperature

## Prompts Of Charging Indicator

Power Indicator	Battery level
Red light is blinking	Charging (<10%)
Green light is blinking	Charging (≥10%)
Green light is normally on	Battery charged

## Printer Cleaning

- The print head should be cleaned in time when the printer has one of the following conditions:

- Unclear printing
- High paper feeding noise
- Dirt adhered to the print head

- The cleaning steps are as below:

- Turn off the power of the printer, open the upper cover, if there is paper, remove it;
- If printing has been just completed, please wait for the print head to completely cool down;
- Wipe off dust and stains on the surface of the print head with a soft cotton cloth dipped in anhydrous ethanol (which should be wrung dry);
- After the anhydrous ethanol has completely evaporated, load the paper and then close the upper cover to retest the printing.

## Points for Attention:

- During the daily maintenance of the printer, it is necessary to ensure that the power is turned off;
- Do not touch the surface of the print head with your hands and metal objects, and do not use tools such as tweezers to scratch the surface of the print head, printing glue and sensor;
- Do not use organic solvents such as gasoline and acetone;
- Wait until the anhydrous ethanol completely evaporated, before turning on the power to continue printing;
- This product is equipped with a built-in lithium battery, please do not use it in environment with temperature above 45 °C, do not approach heat sources such as open flames, and do not place or use it in sourcing sunlight, otherwise it will cause explosion or fire hazards;
- Do not disassemble and replace the battery without permission, the replacement battery must use the same specification battery, otherwise there will be a risk of explosion;
- The recycling or disposal of waste batteries should comply with local regulations and product manuals.

## Warning

The manufacturer has the right to modify the contents of the manual without prior declaration!

## Note:

The contents of this manual can not be changed without approval agreed, our company reserves the right to change the product software and hardware in terms of the technology and spare parts. If necessary, users can use it together with the product. You can contact the dealer to find more information. Without permission, no chapter of this manual may be reproduced or disseminated in any form or by any means.